



**Parts Manual
Power Pack
P-550**



TABLE OF CONTENT

POWERPACK HOUSING - PHOTOSHEET.....	3
POWERPACK HOUSING - PARTS.....	4
INTERNAL ASSEMBLY – PHOTOSHEET.....	5-9
INTERNAL ASSEMBLY – PARTS.....	10-12
INTERNAL HOSE/ADAPTER ASSEMBLY – PHOTOSHEET.....	13-18
INTERNAL HOSE ASSEMBLY – PARTS.....	19
INTERNAL ADAPTER ASSEMBLY – PARTS.....	20-21
CLAMP/RF MANIFOLD PHOTOSHEET/PARTS.....	22-23
TOOLBOX PHOTOSHEET/PARTS.....	24-25
CONTROL PANEL PHOTOSHEET/PARTS.....	26-27
REMOTE CONTROL CABLE PENDANT PHOTOSHEET/PARTS.....	28-29
REMOTE CONTROL WIRELESS (OPTIONAL) PHOTOSHEET/PARTS.....	30-31
REMOTE CONTROL EXTENSION CABLE PHOTOSHEET/PARTS.....	32-33
HYDRAULIC CIRCUITRY DRIVE CIRCUITRY DRAWING/PARTS.....	34-35
HYDRAULIC CIRCUITRY RF CIRCUITRY DRAWING/PARTS.....	36-37



POWER PACK HOUSING 600 – PHOTOSHEET






POWER PACK HOUSING 600 – PARTS

ITEMNO.	QTY.	DESCRIPTION	PART NUMBER
001	1	550 Bare Skid	0802101
002	1	550 Door control panel Assembly	0802104
003	1	550 Air exhaustgrille hd oil cooler	0802107
004	1	550 return manifold	0802108
005	1	550 Return manifold support	0802110
006	1	550 oil cooler cover	0802111
007	1	550 couplerplate HD oilcooler	0802114
008	2	550 Mount strip HD oilcooler	0802116
009	1	550 Air intake grille HD cooler	0802119
010	1	550 coolant air intake grille	0802120
011	1	550 coolant air intake grille	0802121
012	2	550 coolant air intake grille	0802122
013	1	550 Manifoldplate 2008	0802123
014	2	DoorClamp	0305004
015	4	H-shackle	0309030
016	4	Door lock (complete)	0504001
017	10	Door hinge	0711006
018	10	Filling peace Door hinge	0801101
019	1	Roofplate 600 Series Rear	0806118
020	1	Roofplate 600 Series Front	0806119
021	1	Frame support 600 Series	0806120
022	4	Door hook RVS	9501013
023	4	Door hook holder RVS	9501014
024	25	Door rubber	9709050
025	1	Door welding assembly left	0807105
026	1	Door welding assembly right	0807108
027	1	Door welding assembly manifold	0807104
028	1	Air inlet housing 600 series (S)	0807109
029	2	Air inlet housing 600 series (L)	0807110
030	1	Door welding assembly oilcooler	0807111
031	1	Air inlet housing oil cooler	0807112
032	8	Synthetic filling piece black	0807113





INTERNAL ASSEMBLY – PHOTOSHEET






INTERNAL ASSEMBLY – PHOTOSHEET




INTERNAL ASSEMBLY – PHOTOSHEET



INTERNAL ASSEMBLY – PHOTOSHEET



INTERNAL ASSEMBLY – PHOTOSHEET



INTERNAL ASSEMBLY – PARTS

ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
001	1	Skid 600 series	0802200
002	1	Optional package 600RF 002	0807602
003	1	Engine CAT C15	550RF0G0
004	1	Air exhaust AKR150 1480*1600*146	0803001
006	1	Hydraulic pump	0802204
008	1	Clamp/RF pump -14 cc	0408006
009	1	Gear pump	0606017
010	1	Clamp/RF manifold 335/550/1000RF	0604201
011	1	Exhaust	0802044
012	2	Heat exchanger	0211046
013	1	Leak oil filter	0304010
014	1	Drive Coupling	0802036
015	2	Mountingset	200099002E
017	1	Returnfilter	0807009
018	1	Fanguard C15	0802209
020	1	Limit switch	0507052
021	1	Mounting plate RVS	0707100
022	1	Fuel filler cap 3"	0303014
023	1	Mounting flange 3"	0303015
024	1	Exhaust expansion joint	0304033
025	1	Butterfly valve 5"	0307005
026	1	Float switch	100.314
027	1	Tankinhoudsmeter	50467004
028	2	S/N plate	9110014
029	1	4/2 Valve	9501040
030	1	Bully	9507005
031	1	Bulb	9507006
032	4	Elbow flange	9507035
033	1	Return Oil Manifold	06330001
034	1	Split flange	22241762
035	1	Split flange	22241635
036	4	Plain washer	30501200
037	4	Hex.socket head screw	3020120006
038	1	Flange SAE Closed counter 3"	0911007
039	0	Hydraulic tube R15x1.5	0902015
040	1	Mounting plate complete	9906043
041	1	Hand pump	20130003
042	6	Motor support RAEM 800 B	9907032
043	2	Battery	0503039
044	1	Earth switch	790.924
045	1	Heat insulation 525RF	0505118
046	1	Hand pump	20130002
047	2	Battery box small	0802027
048	9	Pin bushing (4 pins)	0105013
049	1	Manifold	0010107
050	35	Engine oil Rubia TIR 7400 15W40	0703004
051	3	Inhibitor vat a 200ltr.	0402002

**Parts Manual
Power Pack
P-550**



052	1200	Hydraulic oil	60052001
054	30	Antifreeze Mono-Ethylene-Glycol	100.726
ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
055	2	Safety valve	20152002
056	1	Check valve	0608010
057	1	Sub plate	0010009
058	4	Stud	3015116010
060	1	Male disconnect 1 1/2"	110.690
061	1	Female disconnect 1 1/2"	110.692
062	1	Dust cap	110.955
063	1	Dust plug	110.957
064	2	Eye bolt DIN 580 M16 - ZP	0902027
070	2	SAE flange 3000 PSI 90°	0803002
071	8	Hose clamp	0803003
090	1	Remote control(cable)	335RF0J1
091	1	Female coupl.housing 16p	0603023
092	1	Male coupler housing	9408007
093	1	Plug	9408008
094	1	Plug	9408010
095	4	Clamp light skid	0303030
096	1	Emergency stop pan	0305013
097	1	Emergency stop button	0504014
097	1	Mounting collar	0504015
098	1	Contact block push button	0504016
099	1	Emergency stop dustcap	0612100
100	1	Toolset 3	0701203
110	1	Sticker	0402005
111	1	Sticker	9111013
112	2	Sticker	9412108
113	1	Sticker	9501050
114	1	Sticker	9501051
115	1	Sticker	9501053
116	1	Sticker	9501054
117	1	Sticker	9501057
118	1	Sticker	9501060
119	2	Sticker	9805032
120	2	Sticker	9805033
121	1	Sticker	9805034
122	1	Sticker	9805035
123	1	Sticker	9805036
124	1	Sticker	9501049
125	1	Sticker	9501058
126	2	Logo ICE 600	98PP600
127	1	Tekst "International Construct..."	98PPTXT
128	1	Logo Powerpack Large ICE	98PPICE
129	1	Mass sticker - 7750kg	98M07750
130	1	Sticker	0811038
140	1	Suitcase for power pack	0808037
150	1	Soundisolation kit 600 serie	0807101
151	7	Merfocell PU 50x45x1300mm	0809015
170	1	Suction hose	0809021
171	1	Suction hose	0809022
172	1	Tube clamp	0902016

**Parts Manual
Power Pack
P-550**



173	0	Tube 168.3 x 4 mm - welded	0902017
174	2	Welding socket	0902033
180	1	Mounting kit PVPlus size 4 SAE/B	0803019
181	1	Coupling PVPlus size 4 SAE13T 16/32	0803020

ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
182	1	Flushing kit parker pump 600RF	600RF070
200	1	Controlpanel	0802205
201	1	Motor cable	09220002
202	1	Battery	09220004
203	1	Cable harness lamps	09220005
205	2	Hose clamp	0902009
206	1	Flexible hose - Vacuflex PU-L 180mm	0902008
207	3	Protection hose	50297004
208	10	Protection hose	50297005
209	1	Cable	50191025
210	1	Plug	50160010
211	300	ltr. Gasoil EN 590	
212	1	Ground braid MBJ 70-300-12	0904006
213	5	Remote control cable	0407004
214	1	Kabelwartel	50311161
300	1	O-ring	140.233
301	4	O-ring	110.119
302	2	O-ring	100.037
303	2	O-ring	400.379
304	1	O-ring plate	0010008
305	2	O-ring	0803005
306	1	O-ring	0711053

****** Heat exchanger **0211046** consisting of:

Oil cooler (loose) 0508059
 Fan 0508057
 Hydromotor 0508058

****** Leak oil filter **0304010**.

Leak oil filter element : 0304011







****** Return oil filter **0807009**

Return oil filter element : 20111091





****** Engine **550RF0G0**

Primary Air filter : 0002015
 Secondary Air filter : 0002016
 Fuel filter : 110.996 + 0603034
 Oil filter : 0603035
 V-Belt set Fan Drive : 0311007
 V-Belt Alternator 0311005
 Alternator 0603038
 Key 0306041







INTERNAL HOSE / ADAPTER ASSEMBLY – PHOTOSHEET







INTERNAL HOSE / ADAPTER ASSEMBLY – PHOTOSHEET







INTERNAL HOSE - ADAPTER ASSEMBLY – PHOTOSHEET






INTERNAL HOSE - ADAPTER – PHOTOSHEET



INTERNAL HOSE - ADAPTER – PHOTOSHEET



INTERNAL HOSE - ADAPTER – PHOTOSHEET



1 INTERNAL HOSE ASSEMBLY

ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
001	2	HOSE038R02V918V018L02280	0401001
002	2	HOSE038R02V016V916L01700	9810016
003	2	HOSE038R02V918V018L01970	0401002
004	2	HOSE125R02V045V045L05120	0306006
005	2	HOSE125R02V045V445L05520	0401014
006	1	HOSE150R02V052V052L04920	0401028
007	1	Hose K-R426NC9203824-1320	0803018
008	1	Hose K-R426NC9203824-1080	0803017
009	1	HOSE075R02V930V030L08070	0401007
010	1	Hose K-492CACF222212-1310	0804036
011	1	Hose K-492CA0121212-1700	0804035
012	1	Hose K-301SNCECA151508-1925	0803012
013	1	HOSE050R02V022P008L05910	0401026
014	1	HOSE038R02V918V018L04610	0401016
015	1	HOSE038R02V918V018L04720	0401015
016	1	HOSE038R02V416V016L04680	0401009
017	1	Hose K-492CACF151508-470	0812074
018	1	HOSE038R02V918V018L02750	0401032
019	1	HOSE050R02J008A022L02160	0701008
020	1	HOSE050PT4Y024Y924L03270	0401018
021	1	HOSE100R02V936V036L14170	0401020
022	1	HOSE038R01V018V918L12300	0511014
023	1	HOSE038R02V418V018L09640	0401005
024	1	HOSE075R02V030V430L14560	0401004
025	1	Hose K-301SNC9C9080804-1750	0806022
026	1	HOSE050R02V922V022L03150	0306019
027	2	HOSE100R02V936V036L04530	0401021
028	1	Hose K-301SN0606060606-680	0803013
029	1	HOSE038R02V418J006L05700	0807028
030	1	HOSE025R01V912V012L00980	0504026
031	1	HOSE038R02J906J906L02960	0401011
032	1	HOSE038R02J906J906L03270	0401010
033	1	HOSE038R02J906J906L02360	0401012
034	1	HOSE038R02J906J906L02760	0401013
035	1	HOSE050R02V022V922L09060	0507073
036	1	Hose K-301SNCFCA424224-980	0807029

2 INTERNAL ADAPTERS

ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
101	2	FITT2C-08Q	100.727
102	3	Straight male stud fitting	2240712715
103	1	FITT2S-08P06P	130.221
104	1	FITT9S-08P22A	9111022
105	1	Ball valve 1/2"	9307002
106	2	Nut FM15LCF	0902014
107	1	Straight male stud fitting	2240912715
108	1	FITT2S-08M06R	0508044
109	2	Adjustable elbow fitting	2243700028
110	1	15L stop	0808038
111	1	Adjustable barrel L-fitting	22438000282
112	1	Adjustable barrel L-fitting	2244300012
113	1	FITT9S-02P12A	9602013
114	1	FITT2S-04Q12P	100.186
115	1	FITT2S-04P04P	110.691
116	1	Elbow fitting	2256314314
117	5	FITT9S-20X04P	9606017
118	1	Straight male stud fitting	2241026916
119	1	Straight male stud fitting	224101431A
120	1	Straight male stud fitting	2241026928
121	1	Adjustable elbow fitting	2243700016
122	1	Straight male stud fitting	2240712716
123	4	FITT2S-06S06M	795.087
124	1	Adjustable barrel L-fitting	2244300015
126	3	Adjustable elbow fitting	2243700022
128	2	Split flange	22242318
129	2	O-ring	100.037
130	1	Adjustable elbow fitting	2243700038
131	1	Straight male stud fitting	2240738138
132	3	Adjustable elbow fitting	2243800042
134	3	Split flange	22241635
135	2	O-ring	41002016
138	7	Plug	20621318
139	4	Plug	20621381
140	2	FITT9S-24S52A	9810007
141	1	O-ring	110.119
142	1	Split flange	22241381
143	1	FITT9S-24F52A	9704041
144	2	Straight male stud fitting	2240628033
145	1	Check valve	9909039
048	1	Adjustable barrel L-fitting	2244300022
049	1	Straight bulkhead fitting	2241400022
050	1	Straight connection	22370222
151	3	FITT9S-16S30A	0307003
152	1	Elbow flange	0302002
153	1	Elbow flange	0301011
154	4	Straight male stud fitting	2240709512
155	4	Straight male stud fitting	2230712712




**Parts Manual
Power Pack
P-550**



156	4	Elbow flange	9507035
157	2	Straight male stud fitting	2240709510
158	1	FITT9L-52A52A	0303023

ITEM NO.	QTY.	DESCRIPTION	PART NUMBER
160	4	Reduced coupling	2242242235
161	2	FITT9T-52A52V52A	9704042
163	1	FITT9T-16A16V16A	0005058
164	2	Adjustable T-connection	2244000012
165	1	Breather	100.455
166	2	Adjustable elbow fitting	2243700035
168	2	FITT9V-45A45V	0604013
169	4	Straight male stud fitting	2249538135
172	1	Split flange	22241762
173	1	Flange SAE Closed counter 3"	0911006
174	1	15L stop	0808038
176	2	Straight male stud fitting	2240712709
177	1	Female disconnect 3/4"	400.095
178	1	Dust plug	400.121
179	1	Dust cap	100.257
180	1	Quick coupling	22752095
181	1	Dust cap	9404010
182	1	Male disconnect 3/8"	9404008
183	1	Dust plug	9404009
184	1	Female disconnect 3/8"	9404007
185	1	Female disconnect 1/2"	9406013
186	1	Dust plug	9406015
187	1	FITT2S-06Q08P	400.357
188	1	Dust plug	22754095
189	1	FITT2S-06Q06Q	110.143
190	1	Quick coupling	22751095
192	3	Test coupling EMA3/1/4EDCF	790.909
193	1	Adjustable elbow fitting	2243800038
194	2	Straight male stud fitting	2240725428
195	1	Split flange	22241508
197	1	Breather	790.524
198	2	Union nut	22364152
199	2	Blanking plug	22369152
200	1	Union nut	22364282
201	1	Blanking plug	22369282
202	1	Union nut	22364222
203	1	Blanking plug	22369222
204	1	Non-return valve	22462152010
206	1	Adjustable elbow fitting	2243700012




3 CLAMP/RF MANIFOLD (0604201) – PHOTOSHEET**



4 CLAMP/RF MANIFOLD (0604201**) - PARTS

ITEM	QTY.	DESCRIPTION	PART NO.
001	6	Pin bushing (4 pins)	0105013
002	1	Clamp/RF manifold	consisting of 0604201
003	5	Solenoid	0604010
004	2	4/3 valve	(V1,V2) 0604008
005	1	4/2 valve	(V3) 0604009
006	1	Relief valve	(RV1) 0604004
007	1	Check valve	9201016
008	1	Pressure switch	(PS1) 0604003
009	12	O-ring	0011043
010	12	SHCS M5 x 30	9312001
011	2	SHCS M5 x 55	9611021
012	2	Relief valve	(RV2/3) 0604005
013	1	Relief valve	(RV4) 0604006
014	4	Pressure transmitter	0601028
015	4	Connector	0603008
016	12	Contact	0604018



TOOLBOX – PHOTOSHEET



TOOLBOX – PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
-	0701203	Toolbox Consisting of:	-
1	790.071	1" Allen Wrench	1
2	9709064	M17 Allen Wrench	1
3	9709061	M14 Allen Wrench	1
4	9709059	M12 Allen Wrench	1
5	9709057	M10 Allen Wrench	1
6	9709055	M8 Allen Wrench	1
7	9709053	M6 Allen Wrench	1
8	100.651	Voltage Tester 24 Volt	1
9	100.687	7/8" Allen Wrench	1
10	100.685	3/4" Allen Wrench	1
11	100.683	5/8" Allen Wrench	1
12	100.681	9/16" Allen Wrench	1
13	100.679	1/2" Allen Wrench	1
14	100.675	3/8" Allen Wrench	1
15	100.657	5/16" Allen Wrench	1
16	100.673	1/4" Allen Wrench	1
17	0507055	Toolbox	1
18	9809001	Slagsl. Kukko 51A	1
19	0707014	M24 Allen Wrench	1


CONTROL PANEL (0802205) PHOTOSHEET



CONTROL PANEL (0802205) PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
001	0601025	PLC Control	1
002	0601027	Connector (25 Pins)	1
003	0507054	Control Panel Box	1
004	0306040	Starter Switch	1
005	0306041	Key	1
006	9408009	Female Coupler Housing	1
007	9408010	Plug Female (16 Pins)	1
008	9408007	Male Coupler Housing	1
009	9408008	Plug Male (16 Pins)	1
010	0601026	Expansion Module	1
011	9711031	Circuit Breaker	1
012	0301016	Circuit Breaker	4
013	0306038	Diode Block (7 Pcs)	1
014	0603004	Relay (Complete)	1
015	-	Resistor	7
016	0305009	Service Tool Connector	1
017	0305010	Dust Cap	2


REMOTE CONTROL – CABLE PENDANT – PHOTOSHEET



REMOTE CONTROL – CABLE PENDANT – PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
-	335RF0J1	Remote Control - Cable Pendant Consisting Of:	
001	0202013	Contact Block	1
002	0407004	Remote Control Cable	15
003	0407005	Name Plate	1
004	0506014	Strain Relief	1
005	9407035	Emergency Stop Button	1
006	9408007	Male Coupler Housing	1
007	9408008	Plug Male (16 Pins)	1
008	9410001	Protective Guard	1
009	9506030	Remote Control Box	1
010	9506033	Stop Button	1
011	9506035	Element	8
012	9506037	Start Button	1
013	9506051	Switch -/+	3
014	9506053	Bulb	1
015	9506054	Lens	1
016	9506055	Clamp Light	1


REMOTE CONTROL – WIRELESS (OPTIONAL) – PHOTOSHEET



REMOTE CONTROL – WIRELESS (OPTIONAL) – PARTS


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
-	9808203	Remote Control – Wireless Consisting of:	-
1	0211039	Text Plate	1
2	0211040	Text Plate	1
3	0211041	Text Plate	1
4	0211042	Text Plate	1
5	9408007	Male Coupler Housing	1
6	9408008	Plug Male (16 Pins)	1
7	0202008	Male Coupler Housing	1
8	0308001	Antenna	1
9	0308002	Coax Cable 3mtr	1
10	9408010	Plug Female (16 Pins)	1
11	9601026	Shock Absorber	4
12	0603013	Battery Compartment	1
13	9611030	Receiver (24VDC)	1
14	0603016	Battery	2
15	9809014	Transmitter	1
16	9809015	Protection Cover	1
17	0402118	Mounting Plate	1
18	0603014	Charging Adapter	1
19	0407004	Remote Control Cable	1
20	0802029	Adapter / Battery	1
21	0603019	Emergency Stop Button	1
22	0603020	Push Button	10
23	0603021	Seal Push Button	10
24	0603022	Body Guard	1

REMOTE CONTROL – EXTENSION CABLE – PHOTOSHEET



005

001
002




003
004

REMOTE CONTROL – EXTENSION CABLE – PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9408007	Male Coupler Housing	1
2	9408008	Plug Male (16 Pins)	5
3	0603023	Female Coupler Housing (16 Pins)	1
4	9408010	Plug Female (16 Pins)	1
5	0407004	Remote Control Cable	5


HYDRAULIC CIRCUITRY – DRIVE CIRCUITRY – DRAWING



HYDRAULIC CIRCUITRY – DRIVE CIRCUITRY – PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
P2	0408006	Clamp Pump	1
MV	0305006	Manual Valve	1
P1	0010002	Drive Pump	1
P3	0010003	Fan Pump	1
FL	100.314	Fluid Level Switch	1
F1	0211059	Return Filter	1
RV1	9906043	Relief Valve	1
V1	9501040	Control Valve	1
HE-1, 2	0211046	Oil Cooler	2
CV1	0608010	Check Valve	1
RV3,4	0010005	Relief Valve	2
QD1	110.692	Quick Disconnect Female	1
QD2	110.690	Quick Disconnect Male	1
F2	0304010	Return Filter Leak-Oil	1
CV2	9909039	Check Valve	1
MP	9909009	Manual Pump	1
QD3	400.095	Quick Disconnect Female	1
TT1	0601029	Temperature Transmitter	1
PT1,2,3	0601028	Pressure Transmitter	3

HYDRAULIC CIRCUITRY – RF CIRCUITRY – DRAWING



HYDRAULIC CIRCUITRY – RF CIRCUITRY – PARTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
CV1	9201016	Check Valve	1
PT1,2,3,4	0601028	Pressure Transmitter	4
PS1	0604003	Pressure Switch	1
QD1,2	100.245	Quick Disconnect	1
QD1,2	100.777	Quick Disconnect	1
QD3,4	9404007	Quick Disconnect	1
QD3,4	9404008	Quick Disconnect	1
RV1	0604004	Relief Valve	1
RV2,3	0604005	Relief Valve	2
RV4	0604006	Relief Valve	1
V1,2	0604008	4/3 Valve	2
V3	0604009	4/2 Valve	1